

MQ-Link固件自動更新說明

V1.7版(含V1.7)以後有此功能

October, 2015

- **MQ-Link**的上位機軟件和下件機固件版本有對應關係, 若不同版本時會不能使用。
- 當**MQ-Link**的軟/固件進版時, 客戶手上的**MQ-Link**若為前一版本時, 請依下列方式進行更新:


步驟1: 先點擊執行檔, 在電腦進行新版**MQ-Link**的安裝, 安裝完即完成上位機軟件的更新。

步驟2: 安裝好後, 啟動 **iMQ i87 IDE**軟體, 進入主畫面。

步驟3: 以**USB**線將**MQ-Link**連接到電腦。

(請繼續見下頁說明)


步驟4:此時, **iMQ i87 IDE**軟體會自動偵測使用者的**MQ-Link**內固件版本不同 (**V1.7版以後有此功能**), 會出現對話框詢問 "是否要更新 (**Would you like to upgrade firmware now?**) "。若要更新, 請按下"確定"鍵。



Please follow the bellow steps to upgrade firmware.
1.Settings -> Firware Upgrade...
2.Browse
3.load firmware file. The Firmware file is in '<iMQ IDE installed folder>\IMQOCD_OSV1.7.1.iup
4.Download!


Hardware detected:
IMQ OCDE BT V1.0.0 MQ-Link00037
iMQ i87-IDE v1.70 (20151012)

步驟5: 出現自動更新的進度條，自動進行固件更新。
(V1.7版以後有此功能)



Hardware detected:
IMQ OCDE BT V1.0.0 MQ-Link00011
IMQ i87-IDE v1.70 (20151012)
Switching to Bootloader mode...
Waiting for Switching to Bootloader mode.....1 second
Now in Bootloader mode. Ready for OS Upgrade.

步驟6: 直到出到 "完成 (OS Download Succeeded)" 的提示, 按下 "確定" 鍵。接下來即可正常使用MQ-Link。



Output Window

Switching to Bootloader mode...
Waiting for Switching to Bootloader mode.....1 second
Now in Bootloader mode. Ready for OS Upgrade.

Hardware Removed.

Hardware detected:
IMQ OCDE OS v1.7.1 BT V1.0.0 MQ-Link00011
iMQ i87-IDE v1.70 (20151012)